



### **SARA CE at a Glance**

- Simple to use - no technical experience needed
- Automatically scans and reads printed material
- Lightning fast Optical Character Recognition
- Human-like reading voices
- Scan bound books
- Selectable languages
- Save files to hard drive or USB thumb drive
- Low vision features – connect to monitor
- Connect to Braille display
- Classic literature starter library of over 200 books
- Read audible books, including DAISY format

Freedom Scientific's SARA™ CE (Scanning And Reading Appliance, Camera Edition) is the next-generation self-contained scanning and reading appliance for the blind and those with low vision.

### **Start reading right away**

The SARA CE is simple to use. Just place a page under the camera, and the SARA CE instantly starts reading it to you with RealSpeak human-sounding speech. No computer experience is needed. You don't even need to push a button to read almost any printed material – books, magazines, mail, and more. The camera automatically senses when a new page is presented.

### **Packed with features**

A built-in keypad with brightly-colored tactile keys provides access to a wealth of additional features. Pause reading, move forward and backward, or hear a word spelled out. Change the reading speed and volume. Select a different voice. Scan and read in one of 18 languages. Change the scanning mode to capture bound books, and save them on the hard drive or a USB thumb drive. Read one of the 222 classic novels that come already installed.

The SARA CE talks you through each step with audible menus. There is even built-in Help and an audible onboard user manual.

## Low Vision Features

Connect a monitor to access the customizable low vision features. Increase the text size. Change text and background colors. Add more space between letters, and highlight words as they are spoken.

## Fast, automatic page capture

In automatic mode, the SARA CE senses motion, so it knows to snap an image whenever you turn a page. Place your paperback novel sideways, and the SARA CE will snap two pages at a time and maintain the pagination. You can keep turning pages and capturing images while the SARA CE reads to you.

## More SARA CE Features

- Save files stored on USB thumb drives
- Scan in Background option allows you to continue scanning the next page while reading the first
- 35 interchangeable text and monitor background color combinations for the best readability
- Supports scanning and reading in multiple languages and additional dialects: U.S. English, British English, Australian English, Belgian Dutch, Brazilian, Danish, Continental French, Canadian French, German, Italian, Norwegian, Polish, Portuguese, Basque, Czech, Turkish, Greek, Russian, Castilian and Latin American Spanish, Finnish, and Swedish
- Opens a variety of file types from USB
- Independent keyboard Help for document reading, menus, dialogs, and playing audio books



*Easy-to-use, large color-coded keys with raised markings*

---

## Specifications

**Size:** 12 by 15.5 by 3.9 inches (30.5 by 39.4 by 9.9 centimeters)

**Camera Height Above Base:** 16 inches (40.5 centimeters)

**Approximate weight:** 6.4 pounds (2.9 kilograms)

**Power** 100 - 240 volts



Designed & Assembled  
in the USA

## Contact your local dealer or contact us at:

Freedom Scientific  
11800 31st Court North  
St. Petersburg, Florida 33716-1805  
Sales: 800-444-4443  
info@FreedomScientific.com  
www.FreedomScientific.com