



SARA CE at a Glance

- Simple to use - no technical experience needed
- Automatically scans and reads printed material
- Lightning fast Optical Character Recognition
- Human-like reading voices
- Scan bound books
- Selectable languages
- Save files to hard drive or USB thumb drive
- Low vision features – connect to monitor
- Connect to Braille display
- Classic literature starter library of over 200 books
- Read audio books, including DAISY format

Freedom Scientific's SARA™ CE (Scanning And Reading Appliance, Camera Edition) is the next-generation self-contained scanning and reading appliance for the blind and those with low vision.

Packed with Features

The SARA CE is simple to use. Just place a printed page under the camera, and the SARA CE instantly starts reading it to you with RealSpeak™ human-sounding speech. No computer experience is needed. You don't even need to push a button to read almost any printed material – books, magazines, mail, and more. The camera automatically senses when a new page is presented.

A built-in keypad with brightly-colored tactile keys provides access to a wealth of additional features. Pause reading, move forward and backward, or hear a word spelled out. Change the reading speed and volume. Select a different voice. Scan and read in one of 18 languages. Change the scanning mode to capture bound books, and save them on the 160GB hard drive or a USB thumb drive. Read one of the 222 classic novels that come already installed.

The SARA CE talks you through each step with audible menus. There is even built-in Help and an audible onboard user manual.

Low vision features

Connect a monitor to access the customizable low vision features. Increase the text size. Change text and background colors. Add more space between letters, and highlight words as they are spoken.

Fast, automatic page capture

In automatic mode, the SARA CE senses motion, so it knows to snap an image whenever you turn a page. Place your paperback novel sideways, and the SARA CE will snap two pages at a time. You can keep turning pages and capturing images while the SARA CE reads to you.

More SARA CE features

- Save files stored on USB thumb drives
- Scan in Background option allows you to continue scanning the next page while reading the first
- 35 interchangeable text and monitor background color combinations for the best readability (monitor not included)
- Supports scanning and reading in multiple languages and additional dialects: U.S. English, British English, Australian English, Belgian Dutch, Brazilian, Danish, Continental French, Canadian French, German, Italian, Norwegian, Polish, Portuguese, Basque, Czech, Turkish, Greek, Russian, Castilian and Latin American Spanish, Finnish, and Swedish
- Opens a variety of file types from USB
- Independent keyboard Help for document reading, menus, dialogs, and playing audio books



Easy-to-use, large color-coded keys with raised markings

Specifications

Size: 12 by 15.5 by 3.9 inches (30.5 by 39.4 by 9.9 centimeters)

Camera Height Above Base: 16 inches (40.5 centimeters)

Weight: 6.4 pounds (2.9 kilograms)

Power: 100 - 240 volts

Onboard Storage: 160GB hard drive



Designed & Assembled
in the USA

Contact your local dealer or contact us at:

Freedom Scientific
11800 31st Court North
St. Petersburg, Florida 33716-1805
Sales: 800-444-4443
info@FreedomScientific.com
www.FreedomScientific.com